



AQUATICA™









Digital

LENS CHART

For A6300 & A6500

Lens chart for Sony A6300 & A6500

updated June 14, 2019

*18405: 8" acrylic dome port	*18408: 8" glass dome port	18430: Mini Macro Port	30200: 4" Fisheye dome port
			
30205: SW8 Super Wide 8" acrylic dome port	30208: O-60 Macro port	30209: P-45 Macro port	30202: Flat Port with Acrylic Front
			

LENS	Port	Extension	Focus Gear	Zoom gear
Sony E 16mm f/2.8 with Fisheye converter VCL-ECF1	30200	30600	30502	-
Sony E 10-18mm f/4 OSS	30205	30605	-	30512
Sony 16-50mm f/3.5-5.6 OSS	30205	30602	-	30513
	30209	-	-	30513
Sony 18-55mm f/3.5-5.6 OSS	30205	30601	-	30501
Zeiss Touit 12mm f/2.8 (Sony E-Mount)	18405/18408	30616	30514	-

Macro	Port	Extension	Focus Gear	Zoom gear
Sony 30mm E f/2.8	30202	30601	-	-
Sony FE 50mm f/2.8 Macro	30208	30605	-	-
Sony FE 90mm f/2.8 macro G OSS (Auto Focus)	18430	30616	-	-