






Lens chart for
Sony a7r III & a7 III



Updated Sept.28, 2018

18405: 8" acrylic dome port	18407: 9.25" glass dome port	18408: 8" glass dome port	18409: 6" acrylic dome port	18430: Mini macro port
				

LENS	Port	Extension	Focus Gear	Manual focus extension	Zoom gear
SONY					
Vario Tessar T* 16-35mm f/4 ZA OSS	18405/18407/18408	48459	-	-	49100
Sony FE 28mm f/2 & Fisheye Adaptor	18405/18407/18408	48457	49101	-	-
Sony FE 12-24mm f/4 G	18405/18407/18408	48458	-	-	49107
Sony FE 16-35mm f/2.8 GM	18405/18407/18408	48454	-	-	49105
	18405/18407/18408	-	49106	48469	49105
Vario Tessar T* FE 2470mm f4 ZA OSS	18405/18407/18408	TBD	TBD	TBD	TBD

CANON & Metabone adapter	Port	Extension	Focus Gear	Manual focus extension	Zoom gear
Canon EF 8-15mm f/4L Fisheye	18405/18407/18408/ 18409	48462	-	-	48715
Canon EF 16-35mm f/2.8L USM Type II	18405/18407/18408	48454	-	-	48715
	18405/18407/18408	-	19064	48466	48715
Canon EF 17-40mm f/4L USM	18405/18407/18408	48468	-	-	48715
	18405/18407/18408	-	19065	48467	48715

Macro	Port	Extension	Focus Gear	Manual focus extension	Zoom gear
Sony FE 90mm f/2.8 Macro G OSS	18430	48453	49102	-	-
FE 50 mm F2.8 Macro	18430	TBD	TBD	-	-
Close Up setups for 18430 Macro port	Port	Extension	Focus gear	Holder	Closeup lens
Single Flip holder setup	18430	48453	49102	19355	19352 or 19353
Double Flip holder setup	18430	48453	49102	19356	19352 & 19353
77mm to 66mm Step down Ring setup	18430	48453	49102	19358	19352 or 19353

19352: +5 Close up lens	19353: +10 Close up lens	19356: Double Flip holder	19355: Single Flip holder	19358: 77mm to 67mm Step down ring
