



Canon Type 1 lens chart

For Canon with 1:1 & 1:3 sensors

Camera lens	18407 9.25" dome	18405 8" dome Port	18409 6" dome port		Zoom (Z) or Focus (F) GEAR
	EXTENSION	EXTENSION	EXTENSION	Dome Shade	
Canon EF 14mm f/2.8	18453	18453	18480	NR	(F)18713
Canon EF 15mm f/2.8 Fisheye	Not Needed	Not Needed	18480	18484	(F)18702
Canon EF 20mm f/2.8	18456	18456	18480	18484	(F)18714
Canon EF 16-35mm f/2.8 Type I & II	18457	18457	18480	NR	(Z)18708
Canon EF 17-40mm F/4	18457	18457	18480	NR	(Z) 18709
Sigma 14mm F2.8 EX ASPHERICAL HSM	18462	18462	18480	NR	(F)18697
Sigma 15mm F2.8 FISHEYE	Not Needed	Not Needed	18480	18484	(F)18715
Sigma 15-30mm F3.5-4.5 EX DG	18457	18457	18480	NR	(Z)18698
NR = This lens not recommended for use with this port					
Macro lenses	Port 18428 Auto Focus only		Port 18426 Auto & manual focus		For use with port 18426 only
Canon EF 50mm F2.8	18453		18453		(F)18705
Canon EF 100mm f/2.8	18453		18453		(F)18700
Sigma 50mm F2.8 EX MACRO	Not needed		Not needed		(F)18701