



AQUATICA^{TM.}

Digital









LENS CHART

For A6300 & A6500

Lens chart for
Sony A6300 & A6500



Updated October 5, 2018

*18405: 8" acrylic dome port 	*18408: 8" glass dome port 	18430: Mini Macro Port 	30200: 4" Fisheye dome port 
30205: SW8 Super Wide 8" acrylic dome port 	30208: O-60 Macro port 	30209: P-45 Macro port 	30202: Flat Port with Acrylic Front 

LENS	Port	Extension	Focus Gear	Manual focus extension	Zoom gear
SONY					
Sony E 16mm f/2.8 with Fisheye converter VCL-ECF1	30200	30600	30502	-	-
Sony E 10-18mm f/4 OSS	30205	30605	-	-	30512
Sony 16-50mm f/3.5-5.6 OSS	30205	30602	-	-	30513
	30209	-	-	-	30513
Sony 18-55mm f/3.5-5.6 OSS	30205	30601	-	-	30501

LENS	Port	Extension	Focus Gear	Manual focus extension	Zoom gear
Zeiss Touit 12mm f/2.8 (Sony E-Mount)	18405	30616	30514	-	-
	18408	30616	30514	-	-
Tokina 10-17mm	TBD	TBD	TBD	-	TBD

Macro	Port	Extension	Focus Gear	Manual focus extension	Zoom gear
Sony 30mm E f/2.8	30202	30601	-	-	-
Sony FE 50mm f/2.8 Macro	30208	30605	-	-	-
Sony FE 90mm f/2.8 macro G OSS (Auto Focus)	18430	30616	-	-	-
Sony FE 90mm f/2.8 Macro G OSS (Manual focus)	18426*	30616	30511	-	-

*Macro port 18426 is discontinued. This is for customers with one already.